

SPE BOUNDARY
AND FIRST OF
NINE POH
130

OVERHEAD COLUMNS
110

PAYLOAD COLUMNS
120

SOH
140

LOH
150

1,1	1,2	1,3	1,4	...	1,90
2,1	2,2	2,3	2,4	...	2,90
3,1	3,2	3,3	3,4	...	3,90
4,1	4,2	4,3	4,4	...	4,90
5,1	5,2	5,3	5,4	...	5,90
6,1	6,2	6,3	6,4	...	6,90
7,1	7,2	7,3	7,4	...	7,90
8,1	8,2	8,3	8,4	...	8,90
9,1	9,2	9,3	9,4	...	9,90

FIG. 1

FIG. 2




FIG. 3




FIG. 4




FIG. 5




FIG. 6





FIG. 7






FIG. 9




FIG. 10




FIG. 11

MACHINE
READABLE
MEDIUM
1220

MACHINE
EXECUTABLE
INSTRUCTIONS
1210

FIG. 12